


NOTES:

1. USE ONLY #8-32 X 3/8 PAN HEAD SCREWS (.094 MAXIMUM HEAD HEIGHT) TO SECURE CHASSIS BOX TO THE SLIDE CHASSIS SECTION USING THE FIRST AND LAST HOLES WITH A MAXIMUM SPACING BETWEEN SCREWS OF 8.00". (NOT ALL SCREWS SUPPLIED ARE REQUIRED FOR MOUNTING.)
2. MOUNT FRONT OF STATIONARY SECTION AS CLOSE TO FRONT CABINET RAIL AS POSSIBLE, LETTING REAR MOUNTING BRACKET PROVIDE THE ADJUSTMENT.
3. BRACKETS, BAR NUTS, AND #10 SCREWS ARE SUPPLIED WHEN SLIDES ARE ORDERED WITH "CM" CABINET MOUNT BRACKETS. "CM1" STYLE BRACKETS ARE SHOWN, SEE WEBSITE FOR OTHER BRACKET CONFIGURATIONS.
4. RIGHT HAND AND LEFT HAND SLIDE ARE THE SAME. LEFT HAND SHOWN. INVERT SLIDE TO MOUNT RIGHT HAND SIDE.



DEPRESS GREEN BUTTON[®] AND BEGIN REARWARD MOVEMENT TO RELEASE SLIDE FROM STANDARD LOCK-OUT CONDITION.

NON-LOCKING SLIDES WITH AR (AUTOMATIC RELEASE) FEATURE DO NOT REQUIRE SPRING TO BE DEPRESSED BEFORE CLOSING.

TO AID INSTALLATION, DISCONNECT SLIDE BY

DEPRESSING GREEN BUTTON[®] AND MOVING CHASSIS SECTION FORWARD.

MOVE RETAINER TO FRONT END OF INTERMEDIATE SECTION BEFORE INSERTING CHASSIS SECTION.

CLB-307 CABINET MOUNTING
(CC7600 SERIES SLIDES)
(SEE REVERSE SIDE FOR FLAT MOUNTING)




CHASSIS TRAK[®] Telescoping Slides

www.generaldevices.com

If you have questions please call 317-897-7000
or send e-mail to sales@generaldevices.com

NOTES:

1. USE ONLY #8-32 X 3/8 PAN HEAD SCREWS (.094 MAXIMUM HEAD HEIGHT) TO SECURE CHASSIS BOX TO THE SLIDE CHASSIS SECTION USING THE FIRST AND LAST HOLES WITH A MAXIMUM SPACING BETWEEN SCREWS OF 8.00". (NOT ALL SCREWS SUPPLIED ARE REQUIRED FOR MOUNTING.)
2. RIGHT HAND AND LEFT HAND SLIDE ARE THE SAME. LEFT HAND SHOWN. INVERT SLIDE TO MOUNT RIGHT HAND SIDE.



CLB-307 FLAT MOUNTING
(CC7600 SERIES SLIDES)
(SEE REVERSE SIDE FOR CABINET MOUNTING)



CHASSIS TRAK[®] Telescoping Slides

www.generaldevices.com

If you have questions please call 317-897-7000
or send e-mail to sales@generaldevices.com