


NOTES:

1. USE ONLY #8-32 X 3/8 PAN HEAD SCREWS (.094 MAXIMUM HEAD HEIGHT) TO SECURE CHASSIS BOX TO THE SLIDE CHASSIS SECTION USING THE FIRST AND LAST HOLES WITH A MAXIMUM SPACING BETWEEN SCREWS OF 8.00". (NOT ALL SCREWS SUPPLIED ARE REQUIRED FOR MOUNTING.)
2. MOUNT FRONT OF STATIONARY SECTION AS CLOSE TO FRONT CABINET RAIL AS POSSIBLE, LETTING REAR MOUNTING BRACKET PROVIDE THE ADJUSTMENT.
3. BRACKETS, BAR NUTS AND #10 SCREWS ARE SUPPLIED WHEN SLIDES ARE ORDERED WITH "CM" CABINET MOUNT BRACKETS. "CM1" STYLE BRACKETS ARE SHOWN, SEE WEBSITE FOR OTHER BRACKET CONFIGURATIONS.



SLIDE DOES NOT DISCONNECT

C-7100 CABINET MOUNTING
(CC7100 SERIES SLIDES)
(SEE REVERSE SIDE FOR FLAT MOUNTING)




CHASSIS TRAK® Telescoping Slides

www.generaldevices.com

If you have questions please call 317-897-7000
or send e-mail to sales@generaldevices.com

NOTES:

1. USE ONLY #8-32 X 3/8 PAN HEAD SCREWS (.094 MAXIMUM HEAD HEIGHT) TO SECURE CHASSIS BOX TO THE SLIDE CHASSIS SECTION USING THE FIRST AND LAST HOLES WITH A MAXIMUM SPACING BETWEEN SCREWS OF 8.00". (NOT ALL SCREWS SUPPLIED ARE REQUIRED FOR MOUNTING.)



C-7100 FLAT MOUNTING (CC7100 SERIES SLIDES) (SEE REVERSE SIDE FOR CABINET MOUNTING)



CHASSIS TRAK® Telescoping Slides

www.generaldevices.com

If you have questions please call 317-897-7000
or send e-mail to sales@generaldevices.com